


R&S®ROMES4

Drive Test Software

Mobile coverage and QoS measurements in mobile networks



R&S®ROMES4 Drive Test Software At a glance

The R&S®ROMES4 drive test software, the unique scanners and network problem analyzer (NPA) tool from Rohde & Schwarz provide an all-in-one solution for network analysis and optimization.


Universal software platform

R&S®ROMES4 is the universal software platform for network engineering and network optimization systems from Rohde & Schwarz. In combination with other test and measurement equipment such as wireless communications scanners and test mobile phones, it provides solutions for all essential tasks involved in coverage measurements, interference identification, performance measurements and quality analysis in mobile networks. In addition to measuring and displaying test parameters, data is processed instantly and statistics are calculated in realtime.

Support of multiple protocols and standards

R&S®ROMES4 supports 5G NR, GSM/EDGE, WCDMA/HSPA+, CDMA2000® 1xEV-DO Rev. A, WLAN (IEEE 802.11a, b, g, n), WiMAX™ (IEEE 802.16e), LTE, NB-IoT/Cat NB1, LTE-M, DVB-T, DVB-H and TETRA. Standard-compliant RF level measurements can be time- and route-triggered over a very wide frequency range (9 kHz to 7 GHz). Due to its highly modular structure, the platform can be expanded at any time for new technologies. The test software runs on a Windows 7/10 (64 bit) PC.

Straightforward R&S®ROMES4 drive test software user interface



Combination with R&S®TSMx scanners

When R&S®ROMES4 is combined with the R&S®TSMx band-unlimited scanners, the measurements help typical users (such as network operators, regulatory authorities, service providers, chipset manufacturers and government authorities) complete their work quickly and easily.

Key facts

- One software for all technologies from a single source
- Flexible software licenses that meet user requirements reduce startup costs
- Analysis of R&S®TSME6 and R&S®TSMA6 5G NR scanner measurements and 5G Qualcomm based UE measurements
- Parallel measurements with up to eight mobile devices per license save time, allowing more effective utilization of existing resources and saving operating expenses (OPEX)
- High-precision, fast RF test and measurement equipment (Rohde&Schwarz scanners) delivers a large quantity of reliable measurements and results
- Automated analysis at the end of the measurement using the integrated replay function or the network problem analyzer (NPA) considerably reduces OPEX
- Automatic identification of GSM interference considerably reduces OPEX (up to 80% potential savings compared with standard analysis)
- Unique scanner for 5G NR, GSM, WCDMA, CDMA2000® 1xEV-DO, WiMAX™, LTE, NB-IoT/Cat NB1 and TETRA in all bands, decoding of broadcast information



R&S®ROMES4 running on a tablet
with an R&S®TSMA6 scanner



R&S®ROMES4

Drive Test Software

Benefits and key features

Easy operation and high flexibility

- Easy-to-use interface that adapts to the user's level of knowledge
- Ready to use in no time thanks to workspaces and projects
- Easy system configuration with device manager and wizards
- Fast setup due to automatic channel detection
- Support of numerous map data formats
- Powerful analysis tools

▷ [page 6](#)

5G NR network testing

- Analysis of R&S®TSME6 and R&S®TSMA6 scanner measurements on 5G NR synchronization signal blocks (SSB)
- Analysis of 5G NR UE measurements

▷ [page 8](#)

Numerous application tests

- Creation of different application jobs
 - Data throughput measurement on a PC
 - Innovative on-device testing with smartphone
- Output of KPIs and the most important network parameters in a report

▷ [page 10](#)

R&S®ROMES4 with test devices



Automatic handover and neighborhood analysis

- Automatic detection of missing neighboring cells during drive testing
- Improvement of network coverage

▷ [page 12](#)

Testing of voice quality – incl. VoLTE

- User-friendly configuration for checking voice quality
- Complete end-to-end measurement from the user perspective
- Based on POLQA standard

▷ [page 13](#)

LTE broadcast (eMBMS) network optimization

- R&S®ROMES4 in combination with a Rohde&Schwarz LTE scanner and an LTE eMBMS test mobile
- Network planning
- Network rollout
- Detection of intersymbol interference
- Check of network configuration
- Validation of network performance

▷ [page 14](#)

LTE downlink allocation analyzer (DLAA) and uplink allocation analyzer (ULAA)

- Allocation analysis of strongest eNodeB in downlink and uplink
- Wide range of applications

▷ [page 16](#)

NB-IoT/Cat NB1 and LTE-M measurements

- Combination with a Rohde&Schwarz scanner
- Support of all operating modes defined in NB-IoT/Cat NB1
- Simultaneous measurements of NB-IoT and other technologies
- Layer 3 decoding
- Combination with an NB-IoT UE
- LTE-M (Cat M1/eMTC) support

▷ [page 18](#)

Full overview of layer 1 and layer 3

- Display of mobile phone activities in layer 3
- Fast analysis of interrupted connections

▷ [page 21](#)

Parallel spectrum measurement

- Broadband spectrum measurement
- Detection of broadband interferers, neighborhood interference and uplink activities

▷ [page 22](#)

Location estimation of 2G/3G/LTE and NB-IoT base stations

- Creation of a base station list during a drive test
- Requires only scanners and GPS

▷ [page 23](#)

GSM interference analysis with automatic interferer identification

- Automatic measurement and identification of interferers from own GSM mobile network
- Evaluation of BCCH and TCH channels allows full-featured analysis
- Detection of adjacent-channel and co-channel interferers

▷ [page 24](#)

Indoor measurements

- Stationary or moving measurements indoors – without GPS signal
- Combined indoor/outdoor measurements

▷ [page 26](#)

R&S®ROMES4NPA: analysis and evaluation of network problems

- Automatic detection, analysis and documentation of trouble spots
- Sophisticated algorithms for supporting users
- Broad range of optional add-on modules for voice quality and data tests as well as coverage and neighborhood analysis
- Comprehensive set of reporting functions

▷ [page 27](#)

Easy operation and high flexibility

Easy-to-use interface that adapts to the user's level of knowledge

Featuring different user levels, R&S®ROMES4 can adapt to the user's level of knowledge. The different levels make it possible to adjust the displayed views and signals to what is most important for the individual user. Experienced and novice users alike finish their work faster.

Ready to use in no time thanks to workspaces and projects


Users can create a workspace in which to store all settings and loaded drivers. At the start of a new drive test, all they need to do is load this workspace and the test system is immediately ready to use.

To further simplify and speed up this procedure, users can create a project. A project contains all the settings of a workspace and reduces the overall volume of the modules to be loaded when the software is started. The startup wizard makes it possible to fully automatically load and start a project, workspace or test file.

Easy system configuration with device manager and wizards

Multiple wizards help users configure a test mobile phone in order to perform application tests such as FTP or HTTP downloads. In just three quick steps, the user is ready to start testing. The device manager integrated in R&S®ROMES4 automatically finds and displays all connected test mobile phones and R&S®TSMx scanner options. With just three mouse clicks, the user can configure numerous application tests such as an FTP download. After successfully loading the drivers, R&S®ROMES4 automatically opens a selection of important windows that display measured data. The test can then be started.

Overview of the R&S®ROMES4 graphical user interface



Route with BTS icons for GSM, UMTS and LTE

L3 protocol messages

Parameter comparison

Fast setup due to automatic channel detection

The R&S®ROMES4ACD automatic channel detection feature enables the R&S®TSMW and R&S®TSMx drive test scanners to automatically detect active channels in a specified band. 5G NR, LTE, UMTS, CDMA2000®/1xEV-DO and NB-IoT networks are supported. The feature can be optionally enhanced by a spectrum scan that significantly speeds up the detection process. This feature eliminates the need to set up channel lists prior to a measurement campaign. The measurement system dynamically identifies new channels and adds them to the workspace during the drive. This is particularly relevant in networks deployed in a shared spectrum with other cellular standards, where channel frequency and channel bandwidth frequently change.

Support of numerous map data formats

In addition to the MapInfo map data format, R&S®ROMES4 also supports OpenStreetMap (OSM). Once downloaded, maps are also available offline. This is particularly important when testing data calls to ensure that measurement results are not affected by map downloads. Measurement results can be exported in ASCII format or converted to a Google Earth format. With the Google Earth format, a drive test can be displayed on a map with no additional effort.

Powerful analysis tools

When multiple, long drive tests need to be automatically evaluated for network errors and the cause for these errors determined, the R&S®ROMES4NPA network problem analyzer is the ideal tool. The base module for displaying ETSI key performance indicators (KPI) and providing an overview of the data in the measurement files is included with R&S®ROMES4. Optional modules for dedicated error analysis of voice or data calls automatically evaluate and display the error causes. Other modules enable analysis of coverage test data and neighborhood relationships as well as delta and comparative analysis. LTE MIMO measurements can also be analyzed and evaluated (see page 40 for more details).

OpenStreetMap (OSM)

OpenStreetMap (OSM) is a user-editable world map that is available at the following internet address:
<http://www.openstreetmap.org/>

OSM is a wiki project in which users can participate by uploading and editing geographical information such as GPS tracking data or the course of a road or river. This world map is growing daily.

OpenStreetMap data can be used freely under the terms of the Creative Commons Attribution-ShareAlike 2.0 license.

Quick overview thanks to automatic channel detection



5G NR network testing

Requirements

- R&S®ROMES4
- R&S®TSME6 or R&S®TSMA6 scanner with R&S®TSME6-K50/R&S®TSMA6-K50 option
- R&S®ROMES4T1E
- 5G UE Qualcomm support:
 - 5G device (Qualcomm chipset)
 - R&S®ROMES4QC
 - R&S®ROMES4NRQ

5G NR is expected to become the leading radio access technology in mobile networks during the next years. New use cases such as ultra high speed internet access, massive numbers of connected devices and low latency connections require a completely new radio interface compared to LTE. This leads to a very flexible physical layer that can be adapted to different use cases to enhance network availability and maximize quality of service – from low latency to ultra high data rate applications.

Another essential building block of the 5G NR physical layer is the use of beamforming technology. It is the key to overcoming the issue of higher path loss due to operating on higher frequencies. Beamforming is even used for synchronization signals that UEs traditionally use to synchronize with the network. In 5G NR, synchronization signals are also used for channel quality estimations, which are the basis for establishing effective data transmissions.



Measurement setup example for 5G NR

Analysis of R&S®TSME6 and R&S®TSMA6 scanner measurements on 5G NR synchronization signal blocks (SSB)

With the R&S®TSME6-K50 or R&S®TSMA6-K50 option, users can measure 5G NR synchronization signal blocks (SSB) and decode the PBCH/MIB content of each detected SSB. 5G NR SSB measurements help verify 5G NR coverage and the effect of beamforming, which is a very complex technology with several components involved. Each SSB can be transmitted on different beams (depending on the network configuration), which can be decoded by the scanner. With different SSBs and beams, the scanner results become three dimensional: power, signal-to-noise and interference measurements for each PCI and SSB/beam index deliver a complete set of data to verify the transmission of each SSB/beam. 5G NR SSB measurements are supported for all SSB subcarrier spacings and transmission cases defined for sub 6 GHz bands.

5G NR UE measurements

With UE specific options – R&S®ROMES4QC and R&S®ROMES4NRQ – users are able to perform dual-port recording for non-standalone (NSA) mode with 5G Qualcomm chipset devices. 5G NR UE support provides LTE information related to 5G as well as the 5G specific NR serving cell information such as NR DL ARFCN, PCI and SSB index, L1 measurement values such as RSRP and RSRQ, L2 PDSCH and PUSCH information, and L3 signaling together with services testing data.

R&S®ROMES4 5G NR GUI displaying the results measured with the R&S®TSME6 scanner



Numerous application tests

Requirements


- R&S®ROMES4
- Test mobile phone
- R&S®ROMES4GSM (GSM driver) or R&S®ROMES4QC (Qualcomm driver)
- R&S®ROMES4SAM (Samsung driver)
- R&S®ROMES4QP (QualiPoc driver)
- Optional:
 - R&S®ROMES4CA or R&S®ROMES4CAU (carrier aggregation drivers for DL or UL, Qualcomm)
 - R&S®ROMES4LAA (licensed assisted access, Qualcomm, requires R&S®ROMES4CA)

Creation of different application jobs

Mobile data calls are the standard today. It is therefore essential that data services be optimized with respect to quality and data throughput. This requires tools that can be used to configure, display and evaluate the different data measurements and packet-switched services. R&S®ROMES4 offers three different test solutions that are based on differing test concepts.

Data throughput measurement on a PC

The R&S®ROMES4 data quality analyzer (DQA) makes it possible to perform data tests using a commercially available mobile device (mobile phone, data stick), where the mobile device either acts as a modem or is connected via NDIS. The test is evaluated on a PC. This ensures that the latest devices are always used for testing and enables fast response to new technologies such as LTE carrier aggregation. DQA jobs can be run in parallel so that users need just a few mouse clicks to generate the high data loads required for LTE CA and start testing. By appropriately linking parallel and sequential jobs, the behavior of internet users can be simulated. The R&S®ROMES4 data quality analyzer supports the following applications, which can be combined in an individual job list: SMS, email (POP3 and IMAP), ping, UDP, FTP, HTTP and video streaming.



The DQA report of a drive test quickly reveals trouble spots

Innovative on-device testing with smartphone

When used together with a suitable QualiPoc Android phone, the R&S®ROMES4QP smartphone option sends all of the messages and analyzes directly to the smartphone. This ensures an almost exact simulation of user behavior. R&S®ROMES4 GUI makes configuration easy and convenient. Up to six wired devices can be controlled in parallel. Depending on the device, voice quality analyses and VoLTE measurements can be performed in addition to data tests (incl. carrier aggregation). R&S®ROMES4 includes the following jobs, which also can be assigned to a job list: email, ping, FTP, HTTP, HTTP capacity test, Call2AnyNumber, double-ended voice quality, MOC DL voice quality, network performance tests and application testing such as Youtube, Ookla, Facebook or WhatsApp.

The QualiPoc Android phone can also be used as a standalone device, for instance for indoor measurements. This increases the flexibility and saves costs, since only one device is needed.


Innovative on-device testing with commercial smartphone

Today's applications often call for very high-speed mobile data transfer, where a USB connection can be a limiting factor. To overcome that limitation, R&S®ROMES4 supports on-device testing also for unmodified commercial or precommercial Android smartphones. Users can test data throughput directly on the device without the limitation imposed by a USB connection. For example, tests can be performed on precommercial devices during initial testing of new features (e.g. higher-order carrier aggregation ¹⁾, licensed-assisted access (LAA) and MIMO 4x4) in the lab or field. The R&S®ROMES4 data quality analyzer supports on-device testing in both ADB mode for FTP, HTTP and capacity tests and QualiPoc unrooted mode, where R&S®ROMES4 executes a QualiPoc installation on the connected commercial smartphone, delivering DQA tests (Wi-Fi, VoLTE, ping, messaging and POLQA call tests) in addition to those provided in ADB mode.

Output of KPIs and the most important network parameters in a report

Automatic realtime analysis generates multiple reports containing key benchmark data. ETSI KPIs are calculated automatically.

¹⁾ Currently up to four carriers in downlink (DL) and two in uplink (UL).



The QualiPoc Android phone can also be used as a standalone device, for instance for indoor measurements

Automatic handover and neighborhood analysis

Requirements

- R&S®ROMES4
- R&S®ROMES4HOA
- R&S®ROMES4T1Q or R&S®ROMES4T1W or R&S®ROMES4T1E
- R&S®TSMW, R&S®TSME or R&S®TSMa scanner
- R&S®TSMx GSM/UMTS scanner
- Test mobile phone
- R&S®ROMES4QC (Qualcomm driver) or R&S®ROMES4SAM (Samsung driver)

Automatic detection of missing neighboring cells during drive testing

Automatic neighborhood analysis is based on a base station list and the base stations' broadcast signals that are decoded by the R&S®TSMx scanners. These system information blocks (UMTS and LTE) or system information types (GSM) include information that is normally used by test mobile phones to identify and monitor relevant neighboring cells. The report containing the measured values of the neighbor channels is forwarded to the base station. If necessary, the base station can use this response to initiate a handover.

Improvement of network coverage

Unlike test mobile phones, the R&S®TSMx scanners see all signals. These signals can be allocated to the relevant neighboring cells. R&S®ROMES4 is thus able to automatically compare the measured data from the scanners and the test mobile phones against a base station list to identify any missing neighboring cells. These missing cells may originate during the setup of a network and, in the worst case, can terminate a call.

The SIB analyzer integrated in R&S®ROMES4 compares the neighboring cells measured by the scanner against those in the base station list. Neighboring cells that were detected but do not appear in the list are marked in yellow, indicating a missing neighborhood. This automatic neighborhood analysis works for UMTS; a comparable functionality exists for GSM. Both work in realtime. For TETRA and LTE, this functionality is included in the R&S®ROMES4NPA network problem analyzer (see page 27).

Detecting a missing neighborhood at a glance

The screenshot shows the 'UMTS Neighbourhood Analyser:1' window. It features a 'Search Time' section with filters for SIB11, PI, 3G MN, 2G MN, Distance (10 m), Duration (10 s), and # of Samples (5). Below this is a table with columns: Problem Node, Type, Time, Distance, and Samples. The table lists various SIB11 mismatch events, such as 'MXUA601, SC:415 [SIB11 Mismatch]' and 'MXUS14K, SC:276 [SIB11 Mismatch]'. The bottom section, 'Analyzer Messages', displays a log of system information blocks (SIB11) found in the database but not in the scanner's list, such as '00:15:54.350 MXUA428 - SC 499: ARFCN 104, BCC 7, NCC 5: GSM BTS <?> found in SIB11 but not in Database as neighbour.'

Problem Node	Type	Time	Distance	Samples
00:11:50,699	SIB11	-	-	-
MXUA601, SC:415 [SIB11 Mismatch]	SIB11	-	-	-
00:12:14,693	SIB11	-	-	-
MXUA601, SC:415 [SIB11 Mismatch]	SIB11	0 s (PI: 0 s, MN: 0 s)	0.0 m (PI: 0.0 m, MN: 0.0 m)	1
00:12:16,113	PI2	0.0 s	0.0 m	-
MXUS14K, SC:276 [SIB11 Mismatch]	SIB11	-	-	-
00:13:05,264	SIB11	-	-	-
MXUS14A, SC:163 [SIB11 Mismatch]	SIB11	-	-	-
00:13:37,189	SIB11	-	-	-
MXUS14E, SC:163 [SIB11 Mismatch]	SIB11	-	-	-
00:14:46,689	SIB11	-	-	-
MXUA42A, SC:448 [SIB11 Mismatch]	SIB11	-	-	-
00:15:00,529	SIB11	-	-	-
MXUA42E, SC:448 [SIB11 Mismatch]	SIB11	-	-	-
00:15:27,410	SIB11	-	-	-
MXUA42B, SC:499 [SIB11 Mismatch]	SIB11	-	-	-
00:15:54,350	SIB11	-	-	-

Analyzer Messages

00:15:54.350 MXUA428 - SC 499: ARFCN 104, BCC 7, NCC 5: GSM BTS <?> found in SIB11 but not in Database as neighbour.
00:15:54.350 MXUA428 - SC 499: ARFCN 61, BCC 1, NCC 4: GSM BTS MXBT84A found in SIB11 but not in Database as neighbour.
00:15:54.350 MXUA428 - SC 499: ARFCN 31, BCC 6, NCC 6: GSM BTS MXBN97A found in SIB11 but not in Database as neighbour.
00:15:54.350 MXUA428 - SC 499: ARFCN 8, BCC 4, NCC 3: GSM BTS <?> found in SIB11 but not in Database as neighbour.
00:15:54.350 MXUA428 - SC 499: ARFCN 10, BCC 5, NCC 6: GSM BTS MXBN97C found in SIB11 but not in Database as neighbour.
00:15:54.350 MXUA428 - SC 499: ARFCN 4, BCC 1, NCC 7: GSM BTS MXBI37A found in SIB11 but not in Database as neighbour.
00:15:54.350 MXUA428 - SC 499: ARFCN 49, BCC 6, NCC 3: GSM BTS MXBW07C found in SIB11 but not in Database as neighbour.
00:15:54.350 MXUA428 - SC 499: ARFCN 77, BCC 7, NCC 4: GSM BTS MXBM56A found in SIB11 but not in Database as neighbour.
00:15:54.350 MXUA428 - SC 499: ARFCN 75, BCC 7, NCC 4: GSM BTS MXBGU3C found in SIB11 but not in Database as neighbour.
00:16:19,802 Node B (UARFCN = 10762, SC = 438) not found in Database
00:16:23,406 Node B (UARFCN = 10766, SC = 438) not found in Database
00:16:28,534 MXUA421 - SC 499: MXB3E1A - ARFCN 76, BCC 4, NCC 4: BTS found in Database as neighbour, but not in SIB11.
00:16:28,534 MXUA421 - SC 499: MXB597A - ARFCN 55, BCC 6, NCC 6: BTS found in Database as neighbour, but not in SIB11.
00:16:28,534 MXUA421 - SC 499: MXB730A - ARFCN 74, BCC 0, NCC 3: BTS found in Database as neighbour, but not in SIB11.
00:16:28,534 MXUA421 - SC 499: MXB809B - ARFCN 62, BCC 0, NCC 6: BTS found in Database as neighbour, but not in SIB11.
00:16:28,534 MXUA421 - SC 499: MXB809B - ARFCN 53, BCC 4, NCC 6: BTS found in Database as neighbour, but not in SIB11.
00:16:28,534 MXUA421 - SC 499: MXB809C - ARFCN 51, BCC 0, NCC 6: BTS found in Database as neighbour, but not in SIB11.

Testing of voice quality – incl. VoLTE

Requirements

- R&S®ROMES4
- R&S®ROMES4QP
- QualiPoc Android QA test mobile phone
- R&S®ROMES4QC (Qualcomm driver)
- R&S®ROMES4SAM (Samsung driver)
- Optional: R&S®ROMES4VO (VoLTE driver)

User-friendly configuration for checking voice quality

Mobile networks must meet increasingly high demands for quality. For testing voice quality, R&S®ROMES4 offers an innovative, full-featured, end-to-end solution that exactly simulates user behavior.

The test mobile phone is connected to the R&S®ROMES4 via USB and configured using a job list. A POLQA algorithm (ITU-T P.863) evaluates the voice quality directly on the phone. The results are displayed live in R&S®ROMES4. The greater the difference between the transmitted voice signal and the reference signal, the poorer the voice quality. This is indicated by the usual mean opinion score (MOS) and can lie between 1 (poor) and 5 (very good).

Complete end-to-end measurement from the user perspective


The measurements can be performed using a fixed-network station, usually a voice-quality server, or another mobile phone. The mobile phone reflects the quality as experienced by a mobile user and also permits HD voice measurements. In contrast, a fixed-network station serves as a reference, enabling the cause of a poor MOS to be found more quickly.

Based on POLQA standard

The R&S®ROMES4QP option and a suitable QualiPoc Android QA can be used to measure calls for the downlink and uplink. For the downlink, the server replays a reference voice signal, and the QualiPoc Android QA connected to R&S®ROMES4 evaluates this received signal. For the uplink, the R&S®ROMES4 test system replays a voice signal and the server uses a POLQA algorithm to evaluate it.

Following a drive test, the measured data can be merged so that the uplink and downlink measurements are available in one log file. The merge process can be skipped if two phones connected to R&S®ROMES4 call each other.

Voice quality measurement (MOS) with Samsung Galaxy S5



LTE broadcast (eMBMS) network optimization

Requirements

- R&S®ROMES4
- R&S®ROMES4T1W or R&S®ROMES4T1E
- R&S®TSMW scanner with R&S®TSMW-K29 and R&S®TSMW-K32 or R&S®TSME scanner with R&S®TSME-K29 and R&S®TSME-K32 or R&S®TSMA scanner with R&S®TSMA-K29 and R&S®TSMA-K32
- Optional for test mobile support: R&S®ROMES4QC and R&S®ROMES4EMO

R&S®ROMES4 in combination with a Rohde & Schwarz LTE scanner and an LTE eMBMS test mobile

LTE broadcast, using the evolved multimedia broadcast multicast service (eMBMS) feature of LTE, allows operators to more efficiently provide services to a large number of subscribers. Instead of transmitting video and data content separately to individual users, broadcast saves network resources, making it attractive for areas such as event venues where a multitude of subscribers request the same type of content.

Enabling broadcast in an LTE network poses challenges for the network operator. It is necessary to ensure continued high quality unicast services and simultaneously provide high-performance broadcast services. The broadcast network consists of a virtual single frequency network (SFN) inside the LTE network, where a set of eNodeBs that are part of the same broadcast area transmit the same downlink signal at the same time. This requires accurate eNodeB synchronization, which is typically not the case in LTE-FDD networks. In addition, intersymbol interference becomes important in the SFN. The eMBMS feature already makes use of the extended cyclic prefix, but when planning and commissioning the broadcast network it is crucial to validate that the network footprint at the given operating frequency does not lead to intersymbol interference.

R&S®ROMES4 in combination with an LTE scanner, such as R&S®TSMW, R&S®TSME or R&S®TSMA, and an eMBMS capable test mobile is the ideal solution for optimizing such a network.

Typical measurement setup with R&S®ROMES4, R&S®TSMA and eMBMS smartphone



Network planning

With the scanner, the LTE network can be baselined in the planning phase, and the network synchronization can be checked against GPS. This allows the network planner to predict potential areas of intersymbol interference and allows planning of the MBSFN area IDs, similar to PCI planning in an LTE unicast network.

Network rollout

During the network rollout and tuning of the broadcast network, the scanner can measure the power (RSRP) and quality (SINR) of each MBSFN area. The engineer can then check the validity of the network planning by comparing it to the results from the field.

Detection of intersymbol interference

The scanner can also be used to detect intersymbol interference. Due to the impulse response measurement per PCI, it can also detect which eNodeB is causing this interference, allowing the engineer to take corrective measures.


Check of network configuration

The scanner decodes the SIB2 and SIB13 broadcast messages that include information on the eMBMS configuration in the network, such as MBSFN subframe configuration from SIB2, and MCCH configuration per MBSFN area from SIB13. So in the field, the engineer can check that the network is configured correctly.

Validation of network performance

While the scanner allows optimization of the RF environment, it is also crucial to validate the network performance with a test mobile. R&S®ROMES4 supports eMBMS test mobiles with a Qualcomm chipset, so the engineer can test the connection to the eMBMS network, view layer 3 and flute messages, capture the IP trace, and therefore analyze problems in the broadcast network. While testing eMBMS, it is important to continue testing the unicast services (data and VoLTE) to ensure that service quality stays at a high level when introducing the eMBMS feature.


R&S®ROMES4 eMBMS scanner view with intersymbol interference analysis



LTE downlink allocation analyzer (DLAA) and uplink allocation analyzer (ULAA)

Requirements

- ▮ R&S®ROMES4
- ▮ R&S®ROMES4T1W or R&S®ROMES4T1E
- ▮ For DLAA
 - R&S®TSMW scanner with R&S®TSMW-K29 and R&S®TSMW-K31 or R&S®TSME scanner with R&S®TSME-K29 and R&S®TSME-K31 or R&S®TSMA scanner with R&S®TSMA-K29 and R&S®TSME-K31
- ▮ For ULAA
 - R&S®TSMW scanner with R&S®TSMW-K29 and R&S®TSMW-K33 or R&S®TSME scanner with R&S®TSME-K29 and R&S®TSME-K33 or R&S®TSMA scanner with R&S®TSMA-K29 and R&S®TSME-K33
- ▮ Optional: R&S®TSMW-K27/R&S®TSME-K27/ R&S®TSMA-K27 RF power scan



Fast overview of resource block allocation, average MCS and target throughput of different RNTIs

Allocation analysis of strongest eNodeB in downlink and uplink

In combination with an R&S®TSMW, R&S®TSME or R&S®TSMA scanner, R&S®ROMES4 offers a unique feature that allows analysis of the downlink and uplink allocations of the strongest eNodeB during measurements. The following information is included:

- Number of RNTIs (UEs) scheduled by the eNodeB for data reception
- Modulation and coding scheme (MCS) and throughput for each detected UE
- Cell allocation

Information is provided per TTI and per resource block. Data can be statistically evaluated to estimate the overall cell load based on throughput and number of users. This information is important during network optimization and troubleshooting as it helps users acquire network data without special maintenance tools such as base station counters.

Wide range of applications

The analysis results for LTE downlink and uplink allocations, for example, can explain the limited throughput of a test mobile phone if the scanner shows that the cell load is high and that there are not enough resources available for the test mobile phone.

In a benchmarking environment, this feature provides deep insight into networks, allowing comparison of traffic load and available capacity for different operators.

Other applications include a network probe to measure the cell load in stationary operation, for example when a base station site owner wants to know the importance of a certain base station before renewing the lease with the network operator.

DLAA: RNTI allocation overview



NB-IoT/Cat NB1 and LTE-M measurements

Requirements

- ▮ R&S®ROMES4
- ▮ R&S®ROMES4T1W or R&S®ROMES4T1E
- ▮ R&S®TSMW scanner with R&S®TSMW-K29 and R&S®TSMW-K34 or R&S®TSME scanner with R&S®TSME-K29 and R&S®TSME-K34 or R&S®TSMA scanner with R&S®TSMA-K29 and R&S®TSMA-K34
- ▮ R&S®ROMES4QC and R&S®ROMES4NBQ for Qualcomm NB-IoT support
- ▮ R&S®ROMES4NBN for Neul NB-IoT UE support
- ▮ R&S®ROMES4QC for Qualcomm LTE-M support

Combination with a Rohde & Schwarz scanner

In combination with an R&S®TSMW, R&S®TSME or R&S®TSMA scanner, R&S®ROMES4 enables IoT measurements in both NB-IoT and LTE-M networks. NB-IoT/Cat NB1 and LTE-M are 3GPP standards for connecting a huge number of things such as smart meters to the internet (IoT).

While traditional LTE standards are mainly aimed at increasing throughput and network capacity, NB-IoT/Cat NB1 and LTE-M focus on low power consumption for IoT devices and highest availability of the connecting links, especially indoors. Indoor measurements require lightweight, ultracompact scanners with low power consumption. For coverage validation, troubleshooting and optimization, R&S®ROMES4 in combination with a Rohde & Schwarz scanner delivers signal power, signal quality, and carrier to interference and noise ratio (CINR) measurements for each available physical cell ID.


NB-IoT scanner TopN view

PCI, power and carrier to interference and noise ratio (CINR) based on S-SYNC

Frame structure type, cyclic prefix information and NB-IoT carrier center frequency

Power, quality, CINR and RSSI based on reference signal measurements for both eNodeB antenna ports (TX0, TX1)

Total power received inside the NB-IoT carrier bandwidth (received signal strength indicator, RSSI)



TopN chart, received power bar for each PCI


Support of all operating modes defined in NB-IoT/Cat NB1

The NB-IoT/Cat NB1 standard defines three operating modes to integrate NB-IoT carriers efficiently into the available spectrum. R&S®ROMES4 supports all three modes. The LTE in-band mode makes the most efficient use of the available spectrum. In this mode, one NB-IoT carrier uses the spectrum of one LTE PRB. The other operating modes – guard-band and stand-alone – allow NB-IoT deployments independently from the LTE spectrum.


Simultaneous measurements of NB-IoT and other technologies

NB-IoT measurements can be performed simultaneously with measurements for other technologies such as GSM, LTE or (W)CDMA. During network optimization or troubleshooting, the impact of the NB-IoT spectrum on adjacent GSM/LTE/(W)CDMA spectra and vice versa can be validated.

NB-IoT scanner TopN signals



NB-IoT UE overview view



NB-IoT RACH retransmission

LTE RACH Procedure List					
Procedure	Time	Result	Tx Po...	ReTx	Ty
RACH	00:01:21	Success	-31 ...	1	Cc
RACH	00:01:22	Success	-26 ...	2	Cc
Trigger	00:01:22	---	---	---	---
MSG1	00:01:22	---	---	---	---
Attempt	00:01:22	---	---	---	---
MSG1	00:01:22	---	---	---	---
MSG2	00:01:22	---	---	---	---
MSG3	00:01:22	---	---	---	---
MSG4	00:01:22	---	---	---	---
Attempt	00:01:22	---	---	---	---
RACH	00:01:22	Success	-30 ...	1	Cc
RACH	00:01:22	Success	-29 ...	1	Cc
RACH	00:01:23	Success	-29 ...	1	Cc
RACH	00:01:23	Success	-29 ...	1	Cc
RACH	00:01:23	Success	-29 ...	1	Cc
RACH	00:01:24	Success	-29 ...	1	Cc
RACH	00:01:24	Success	-29 ...	1	Cc
RACH	00:01:24	Success	-29 ...	1	Cc

RACH Procedure	
Final Result	Success
Final Tx Power	-26 dBm
Final ReTx Count	2
Trigger Count	1
MSG1 Count	2
MSG2 Count	1
MSG3 Count	1
MSG4 Count	1
Attempt Count	2

Layer 3 decoding

The NB-IoT scanner supports layer 3 BCH demodulation (MIB/SIB1). Layer 3 BCH data offers deep network configuration insight and helps optimize troubleshooting. Demodulation is performed on the fly during standard NB-IoT synchronization and reference signal measurements.

BCH/broadcast messages include master information block (MIB) and system information block (SIB) messages. They are demodulated for each cell/PCI and displayed in a tree structure in the new NB-IoT scanner BCH view.

Combination with an NB-IoT UE

In combination with an NB-IoT UE, R&S®ROMES4 enables network performance and service quality measurements in NB-IoT/Cat NB1 networks. This setup permits traditional mobile network testing measurements such as RF conditions (including serving cell allocation and identity, downlink (DL) and uplink (UL) channel performance) and random access channel (RACH) procedure.

It additionally provides information about NB-IoT specific features such as cellular IoT (CIoT), coverage enhancement levels (CE) and eDRX. Dedicated NB efficiency KPIs offer analysis of the used energy and transmission efficiency as power consumption is a key NB-IoT metric.

LTE-M (Cat M1/eMTC) support


LTE-M is fully compatible with existing LTE networks. R&S®ROMES4 supports LTE-M measurements in combination with both a scanner and an LTE-M device. LTE-M is standardized for the LTE in-band mode only. By performing subband measurements with a Rohde&Schwarz LTE scanner, it is possible to evaluate the RF conditions for each physical resource block within an LTE carrier. In combination with an LTE-M device, R&S®ROMES4 can deliver traditional mobile network testing (UL/DL RF conditions, UE state, operator information, serving cell information, RACH procedure). LTE-M specific measurements supported by R&S®ROMES4 include, for example, decoding eDRX, power save mode and coverage enhancement (CE) mode parameters.




NB-IoT measurements with R&S®ROMES4
and R&S®TSMA autonomous mobile network scanner

Full overview of layer 1 and layer 3

Parallel jobs are configured with simple graphics



Layer 3 protocol messages for uplink and downlink



Requirements

- R&S®ROMES4
- Test mobile phone
- R&S®ROMES4GSM (GSM driver) or R&S®ROMES4QC (Qualcomm driver) or R&S®ROMES4SAM (Samsung driver) or R&S®ROMES4QP (QualiPoc driver) or R&S®ROMES4TED (Sepura TETRA driver)

Display of mobile phone activities in layer 3

The basic functionality of R&S®ROMES4 in combination with the drivers for test mobile phones provides a large amount of information from layers 1 and 3. Users can see the radio conditions (GSM or WCDMA, channel, voice codec, etc.) for phone calls at a glance.

If measurements are also taken by a scanner, the scanner's measured data is displayed in the same window, allowing a direct comparison.


Layer 3 View displays all the messages, sorted by up-link and downlink. Each message is decoded and can be opened if necessary.

Fast analysis of interrupted connections

In addition to protocol messages, interrupted/blocked and successful connections are also displayed. When jumping to a trouble spot, all views will show measurements taken at this point in time. This makes it considerably easier to find the cause of a problem.

In addition, a filter function in Layer 3 View enables users to evaluate only specific messages.

Overview of all important network parameters



Parallel spectrum measurement

Requirements

- R&S®ROMES4
- R&S®ROMES4T1Q or R&S®ROMES4T1W or R&S®ROMES4T1E
- R&S®TSMx scanner with R&S®TSMU-K17 RF power scan
- R&S®TSMx scanner with R&S®TSMW-K27 RF power scan
- R&S®TSME scanner with R&S®TSME-K27 RF power scan
- R&S®TSMA scanner with R&S®TSMA-K27 RF power scan

Broadband spectrum measurement

In combination with an R&S®TSMU-CW, R&S®TSMW, R&S®TSME or R&S®TSMA scanner, R&S®ROMES4 can be used to perform a spectrum scan. The user can select up to 32 frequency ranges from 80 MHz to 3 GHz (R&S®TSMW: 30 MHz to 6 GHz; R&S®TSME/R&S®TSMA: 350 MHz to 4.4 GHz). The frequency range is not limited. R&S®ROMES4 offers different display options, e.g. envelope spectrum measurement, RMS, peak or a predefined channel mask. In this case, the power per channel is displayed.

Marker functions make it easy to precisely measure dedicated frequencies and detect changes. A marker can also be defined as a reference and compared against the maximum value.

Detection of broadband interferers, neighborhood interference and uplink activities

The waterfall diagram gives the user a general idea of the air interface and its history. This makes it very easy to locate broadband interferers or external interference. All the user needs to do is move the mouse pointer over the waterfall diagram. At any desired spot, timestamp and frequency are displayed, enabling the user to find the center frequency of an unknown signal faster.

The spectrum function is based on FFT analysis. Various FFT sizes allow users to set measurement bandwidths down to min. 140 Hz. The smaller the measurement bandwidth, the greater the measurement accuracy. This permits very fast spectrum measurements without the usual sweep time of a normal spectrum analyzer. Fast measurements are especially important during drive tests in order to obtain a sufficiently high density of results during the drive.

A special threshold value is provided for monitoring the spectrum. Spectra that do not show any test points above this threshold value are not displayed. Any data that is not of interest is not recorded.

Frequency markers and the entire spectrum can be exported to ASCII format.

Spectrum measurement



Five user-selectable frequency ranges for spectrum measurements

Zoom display of one of the five ranges (here the first range "0" from 80 MHz to 2.5 GHz)

Waterfall display of selected range

Location estimation of 2G/3G/LTE and NB-IoT base stations

Requirements

- R&S®ROMES4
- R&S®ROMES4LOC
- R&S®ROMES4T1W or
- R&S®ROMES4T1E
- R&S®TSMW scanner or
- R&S®TSME scanner or
- R&S®TSMA scanner

Creation of a base station list during a drive test

The R&S®TSMW, R&S®TSME and R&S®TSMA scanners enable users to estimate the geographic position of base stations. This can even be done for GSM, WCDMA, CDMA2000® 1xEV-DO, LTE and NB-IoT base stations in parallel.

Requires only scanners and GPS

For the calculation algorithm, all that is needed are the measurement parameters from a highly accurate GPS receiver with output of the PPS time reference signal (pre-installed in the R&S®TSMW, R&S®TSME and R&S®TSMA) and from the 2G/3G/4G scanner.


The R&S®ROMES4 software and the R&S®ROMES4LOC driver allow the scanners not only to detect the main levels of the BTS (2G: RxLev, 3G: RSCP, 4G: RSRP) but also to demodulate the broadcast channels (BCH). Important time information as well as details of the transmitting BTS are thus obtained.

The maximum likelihood method is used to calculate the geographic position of the individual BTS from the measured data provided by the GPS receiver, BCH time information and level changes during the drive test.

Following the drive test, the calculation results are exported to a base station list and the located base stations are displayed on an underlying street map.

Selecting the BTS opens another window in which the characteristic data of the BTS is displayed.

The calculated position of a BTS lies within an error ellipse (approx. 200 m) that is also exported. Base stations can be filtered based on the accuracy of location estimation.



Results of the measured geographic position of base stations using the R&S®ROMES4 software and the R&S®ROMES4LOC driver

GSM interference analysis with automatic interferer identification

Requirements

- R&S®ROMES4
- R&S®ROMES4COI
- R&S®ROMES4T1Q or R&S®ROMES4T1W or R&S®ROMES4T1E
- R&S®TSMx GSM scanner
- Test mobile phone
- R&S®ROMES4QC (Qualcomm driver) or R&S®ROMES4SAM (Samsung driver)

Automatic measurement and identification of interferers from own GSM mobile network


R&S®ROMES4 allows GSM interference to be determined automatically and clearly from the own GSM network during the drive test. The actual interferers can be displayed on the underlying street map in Route Track View. This makes it considerably easier to use the software and perform tests, reducing costs dramatically in comparison with conventional methods.

The evaluation is performed in three steps:

- Automatic detection of an interference situation (type, length, location)
- Automatic analysis of the detected interference (test on BCCH and TCH)
- Classification of the actual interferers on the basis of the individual interference situation and pinpointing of the interferers on the street map (interfering base station with channel indication: BCCH, TCH, adjacent channel)

GSM interference analysis with automatic interferer identification – display on the map.

The map shows the position of the interference (cross line), the cell currently providing coverage (S) and the four actually interfering cells (I1, I2, I3 and I4). The markings N1 to N6 show the current neighboring cells. The color of the route indicates the received signal strength of the GSM mobile phone.



Indoor measurements

Requirements

- R&S®ROMES4
- R&S®ROMES4IND
- Test mobile phone and/or scanner
- R&S®ROMES4QC (Qualcomm driver) or R&S®ROMES4SAM (Samsung driver) or R&S®ROMES4TEP or R&S®ROMES4TED (TETRA driver)


Stationary or moving measurements indoors – without GPS signal

High-quality wireless communications coverage inside buildings, e.g. at airports, shopping malls and exhibition halls, is gaining in significance, especially with respect to data traffic. Since GPS reception indoors is limited or nonexistent, R&S®ROMES4 offers an alternative to conventional navigation display (GPS data on a map).

Combined indoor/outdoor measurements

The R&S®ROMES4IND indoor driver option provides a separate means of navigation that makes it possible to display positions on a floor plan. Measurements can be taken at specific points (hot spots, e.g. in conference rooms) or along a specific path (continuous, e.g. in a corridor). Combined DUTs (comprising buildings and outdoor areas such as company premises) can be optimally measured and georeferenced. The software also displays a smooth transition to areas covered by GPS. Measurements of multi-floor buildings are easily handled by displaying the various floors as multiple layers on the map. The wide support of georeferenced and non-georeferenced map formats (tab, jpg, tif, bmp, png) and included import functionalities for iBwave ibwc and AutoCAD DXF files simplifies and speeds up daily work. The layer that corresponds to the floor where the user is located is visible on the map. The complete integration of the indoor functionality into the R&S®ROMES4 map display allows intuitive operation.

Display of a floor plan in hot spot mode



R&S®ROMES4NPA: analysis and evaluation of network problems

Requirements

- R&S®ROMES4NPA
(included in R&S®ROMES4 or as standalone)
- R&S®ROMES4N11
- R&S®ROMES4N15
- R&S®ROMES4N17
- R&S®ROMES4N18
- R&S®ROMES4N19
- R&S®ROMES4N20
- R&S®ROMES4N21
- R&S®ROMES4N22
- R&S®ROMES4N23
- R&S®ROMES4N30
- R&S®ROMES4N31
- R&S®ROMES4N34

Automatic detection, analysis and documentation of trouble spots

The sheer volume of recorded data makes individual and manual analysis impossible. The data (from R&S®ROMES4 or QP files, after conversion in the latter case) is therefore automatically analyzed by the R&S®ROMES4NPA network problem analyzer, which outputs a list of all detected trouble spots and displays them on a map using Google Maps, OpenStreetMap (OSM) or user-defined maps. R&S®ROMES4NPA also provides information about the cause of the problem.

Sophisticated algorithms for supporting users

The easy-to-use interface guides the user through the process, from reading in the measured data (from one or more drive tests) and selecting the analysis criteria to retrieving the automatically generated list of trouble spots.


Right-clicking a problem automatically opens R&S®ROMES4 and positions the replay of the measurement file just ahead of the trouble spot in question so that the user can perform a detailed check if required. The result is displayed in HTML in a clear report that is ready for printing. Export to Excel allows easy data processing.

The measurement data is analyzed according to specific criteria that depend on the modules selected. In all modules, the analysis criteria can be adapted to user-specific limit values and settings.

The R&S®ROMES4NPA base package includes the following modules:

- NQA (network quality analyzer) for voice calls, base module including KPIs
- DOA (data quality analyzer) for PS data connections, base module including KPIs

Start screen of R&S®ROMES4NPA



Broad range of optional add-on modules for voice quality and data tests as well as coverage and neighborhood analysis

R&S®ROMES4N11

NQA for GSM/WCDMA/TETRA voice calls, expansion for problem spot detection

This module enables analysis of voice calls for network problems, which can be selected from more than 140 different problem categories, and delivers a list of the problem spots including the type and cause of problem.

R&S®ROMES4N15

Coverage module with display of coverage data on a raster map


Coverage data (GSM, WCDMA, CDMA2000® 1xEV-DO, TETRA, LTE, LTE-M) measured with Rohde&Schwarz scanners is rasterized and displayed on a map using Google Maps or OpenStreetMap (OSM). This makes it easy to generate coverage plots and create and visualize overshooting problems. Optimizations can be checked using a before-and-after comparison.

R&S®ROMES4N17

Neighborhood analysis module for automatic classification of neighborhood relationships into one of the following categories

- (Potentially) missing neighbor: a cell with high signal strength and good quality (both thresholds can be set) has been measured but is not contained in the currently defined neighbors
- Unused neighbor: a cell is configured as neighbor but has not been detected during measurement
- Approved neighbor: a cell has been classified as a (potentially) missing neighbor and is contained in the neighbor list. Analysis of intra-RAT handover in the network problem analyzer (NPA) is available for GSM, UMTS, LTE and TETRA. Inter-RAT handovers are currently limited to GSM and UMTS, but will soon be available for LTE as well.

Initial overview of scanner measurement content



R&S®ROMES4N18

Spectrum analysis module for automatic detection of strong transmitters in a spectrum thought to be empty

- Easy verification that a purchased spectrum is clear and that no other emitter still occupies part of that band
- Fast confirmation that part of a spectrum can be used for refarming purposes
- Reliable observation of power scan measurements, similar to a spectrum analyzer
- Automated and configurable (bandwidth, duration, power) analysis from potential narrowband and wideband interferers
- Detailed analysis by drilling down to the corresponding measurement file

R&S®ROMES4N19

BTS evaluation – summary of key BTS parameters as acceptance criterion


To ensure a consistently high degree of network quality, continuous improvements must be made to the mobile network, such as updating the parameters for a mobile base station, replacing hardware or adding new base stations. Each time such improvements are made, the effects on neighboring base stations as well as the mobile network as a whole must be documented and evaluated. The BTS evaluation on the NPA performs these tasks reliably, fast and cost-effectively.

R&S®ROMES4N20

Data module for EDGE, HSPA+, LTE and LTE-M data links including problem spot detection

This module offers specific analysis of high-speed data links for achievable data rates and analysis of potential problems as well as an IP data analyzer for analyzing IP-based data traffic and associated problems. When IP-based data services are used, e.g. web browsing or email, this module analyzes the results and shows problem spots and their cause. A comprehensive collection of different analyses is available especially for LTE.

Display of all neighbors of a cell



R&S®ROMES4N21

Carrier aggregation analysis (downlink)

As the use of data is increasing exponentially, mobile networks need to provide higher-speed data links to their customers. When downlink carrier aggregation is used to provide this capability, this module analyzes the results and shows detailed information such as how many carriers are assigned to a mobile phone and its downlink and uplink throughputs. It also provides statistics (RSRP, RSRO, etc.) for each carrier as well for investigation purposes.

R&S®ROMES4N22

VoLTE analysis

LTE is also increasingly used for voice transmission. IP-based telephony via VoLTE places higher demands on network quality because users have less tolerance for poor voice call quality, such as dropped calls, than they do for data calls. This module automatically analyzes SIP and layer 3 messages as well as call setup KPIs and spots problems if there are timing issues at the SIP level.

R&S®ROMES4N23

Carrier aggregation analysis (uplink)


As the use of data is increasing exponentially, mobile networks need to provide higher-speed data links to their customers. When uplink carrier aggregation is used to provide this capability, this module analyzes the results and shows detailed information such as how many carriers a mobile phone uses in uplink as well as the uplink throughput and number of resource blocks used.

R&S®ROMES4N30

Delta and comparative analysis of R&S®ROMES4 measurement data

This add-on module enables quick comparison of measurement data, for example for visualizing the effects of an implemented network optimization. Measurement data from different cells, UEs or operators can also be compared for benchmarking.

Display of the cells providing coverage on the map



R&S®ROMES4N31

LTE MIMO and downlink allocation analyzer

LTE MIMO analysis is performed based on the condition number (CN) and rank indicator (RI) values measured by the scanner. If mobile device data is available for the analysis, the efficiency per Hz or resource block is also included in the analysis. Any inconsistencies in the condition number, efficiency per resource block or condition number matrix are displayed as problem spots on the map and designated in tables.

The result analysis from the downlink allocation analyzer lists the cell throughput per TTI and operator as well as maximum and average cell throughput in a table and graphically.

R&S®ROMES4N34

NB-IoT analyzer


This module delivers dedicated coverage and problem spot reporting as well as cell statistics for NB-IoT analysis based on scanner measurements.

R&S®ROMES4N35

NB-IoT UE analyzer

This module delivers dedicated coverage and problem spot reporting as well as cell statistics for NB-IoT analysis based on UE measurements.

NPA analysis identifies LTE MIMO problems based on scanner and smartphone measurements



Comprehensive set of reporting functions


If multiple drive tests are selected, the user can draw statistical conclusions about quality in the measured areas. A comparison between various network operators in the same area is also possible (benchmarking).

A further way to evaluate analysis results in greater detail is to use sophisticated filter algorithms (e.g. for examining only one operator/one cell or only specific times or days of the week). The dynamic context filter algorithm makes this even easier and faster. For analyzing dedicated geographical areas, polygon filters can easily be drawn on the map. The result analysis and statistics are automatically tuned to the active filters.


Automated analysis with R&S®ROMES4NPA considerably saves time and reduces costs. Optimizing the results no longer requires time-consuming manual checks and analysis of data that may not even contain any problems.

R&S®ROMES4NPA uses sophisticated algorithms to help users find problem causes. More in-depth analyses can be performed at any time. A large amount of measured data can be automatically and quickly processed; reports (for management and for general documentation) are generated without requiring user interaction.


Random access statistics distributed on CE level as a part of the analysis enabled by NB-IoT analyzer



LTE neighborhood analysis: map, list of the actual, possible and unused neighbors of several cells



LTE handover analysis: map, KPIs and detailed list



System configuration for different application scenarios

R&S®MNT-CORE2

R&S®MNT-CORE2 is a ruggedized, flexible and future-ready hardware concept that best demonstrates its exclusive benefits, its endurance and performance, and its unique flexibility in practice. Its key hardware features and benefits include:

A well thought-out product design

Practical design

The compact and comfortable backpack has an inconspicuous design and is ideal for walk tests in public areas.

Lightweight and adjustable construction

The fully configurable backpack, including four batteries, weighs less than 9 kg. The carrying straps can be individually adjusted to offer best wearing comfort.

Maximum flexibility and future readiness

Flexible measurement configuration

The backpack can accommodate scanners, smartphones, TETRA mobile and a compact PC to support a wide variety of measurement tasks.

Multidevice ready

The smart fixation system is compatible with different smartphone designs and ensures convenient integration of future smartphone models.

Multi-usage

The smartphones are easily removed and can also be used as QualiPoc handheld measurement devices.



R&S®MNT-CORE2 backpack



User-specific cabling

Reliable functionality for uninterrupted data collection

Active cooling

Two fans provide effective cooling and airflow, ensuring uninterrupted and reliable performance of all embedded system components.

Smart power management

A strong power supply consisting of four powerful and hot swappable batteries ensures autonomy of up to eight hours.

R&S®ROMES4 configurations

R&S®ROMES4 and the connected measuring equipment (test mobile phones, R&S®TSMx scanners, etc.) can also be used and delivered in the following configurations on request:

- User-specific cabling/configured by customer
- As a test suitcase
- As a turnkey test vehicle



Test suitcase



Turnkey test vehicle

R&S®MNT-CORE2 specifications

Power rating

Input voltage range		16 V to 19 V DC
Input power		max. 200 W
Input current		max. 10.5 A
Autonomy		typ. 7.5 h
Charging time (four batteries)	QualiPoc Freerider FR3-O	approx. 3.5 h/100 %
	QualiPoc Freerider FR3-V	approx. 6 h/85 %
	QualiPoc Freerider FR3-OB	approx. 5 h/100 %

Environmental conditions

Operating temperature range	max. temperature limited by assembled devices (for R&S®TSMA/R&S®TSME max. +40°C); for smartphones cf. specifications	–10°C to +50°C, system start higher than 0°C
Damp heat		+25°C/+40°C, 95% rel. humidity, cyclic, in line with EN 60068-2-30
Rain protection		IPx3, in line with EN 60529

Mechanical resistance

Shock		30 g/6 ms, in line with IEC/EN 60068-2-27
Bumps		15 g/6 ms, in line with IEC/EN 60068-2-27
Vibration		PSD = 2 m²/s³ at f = 4 Hz to 40 Hz, –6 dB/octave at f > 40 Hz, in line with IEC/EN 60068-2-64
Drop test	free fall	h = 10 cm, in line with IEC 60068-2-32
	drop and topple	h = 10 cm, in line with IEC 60068-2-31

Conformity

Electromagnetic compatibility	EU	in line with ETSI EN301489-1, ETSI EN301489-7, ETSI EN301489-24
Electrical safety	EU	in line with EN 61010-1

General data

Dimensions	W × H × D	287 mm × 542 mm × 140 mm (11.3 in × 21.3 in × 5.5 in)
Weight	R&S®MNT-CORE2 backpack system	3.9 kg (8.6 lb) + 1.5 kg (3.3 lb) for the backpack itself
	fully equipped (four mobile devices, R&S®TSMA, R&S®TSME)	8.2 kg (18.1 lb)
	R&S®MNT-BP89WH battery	0.45 kg (1 lb)

System components

Technology	GSM driver	Qualcomm CDMA2000® 1xEV-DO driver	Exynos (Samsung) driver, Qualcomm driver	TETRA driver	Qualcomm 5G UE driver	Qualcomm IoT driver, Neul IoT driver	R&S®TSMAS driver, R&S®TSMES driver, R&S®TSMW driver	R&S®TSMAS6 driver, R&S®TSMES6 driver	R&S®TSMC-CW driver
GSM/GPRS	•		•				•	•	•
EDGE	•		•				•	•	•
WCDMA Rel. 99			•				•	•	•
HSPA+			•				•	•	•
CDMA2000® 1xEV-DO		•					•	•	•
WiMAX™ IEEE802.16e							•	•	
LTE			•				•	•	
Spectrum							•	•	•
CW power									•
TETRA				•			•	•	
NB-IoT						•	•	•	
5G					•			•	

A list of test mobile phones supported by R&S®ROMES4 is available separately.

System requirements

Recommended:

- Intel Core i7
- 8 Gbyte RAM for Windows 7/10, 64 bit
- 255 Gbyte SSD
- DVD ROM drive
- USB 2.0 and LAN ports
- 15" monitor with a resolution of 1024 × 768 pixel
- Windows 7/10, 64 bit

Recommended notebook

- Dell Latitude E6540 (or newer)

Application: TETRA

Requirements

- R&S®TSMW drive test scanner
- R&S®TSMW-K26 TETRA option for R&S®TSMW
- R&S®ROMES4
- R&S®ROMES4T1W
- R&S®ROMES4TED
- R&S®ROMES4TEP

R&S®ROMES4 is the software platform for measurements on the TETRA air interface. Statistics, analyses, troubleshooting for coverage, quality of service and handover behavior give network operators a complete overview of the network state and help them maintain it in the best possible state.

The R&S®TSMW scanner, TETRA radios and other accessories are controlled by R&S®ROMES4. For such tasks, the following capabilities are indispensable:

- Mobility and speed – use in vehicles, helicopters and on foot
- Highly accurate coverage measurements on TETRA networks using a passive RF scanner
- Spectrum analysis for identifying interferers
- Measurement and identification of TETRA base stations
- Subsequent problem analysis – uncovers problems in the TETRA network and analyzes them based on the test data obtained with R&S®ROMES4

The R&S®TSMW scanner, TETRA radios and other accessories are controlled by R&S®ROMES4




In the downlink, measurements performed using the R&S®TSMW in the D-CT and D-CTT operating modes include the following:

- 100 MHz to 1000 MHz frequency range, with parallel measurements of all channels in a 10 MHz block
- 25 kHz channel resolution (with QPSK)
- Automatic detection of the broadcast synchronization channel (BSCH)
- Up to 20 Hz measurement rate for carrier measurements of up to 2×600 channels simultaneously (10 MHz block, QPSK) with:
 - Channel number and frequency
 - Power of each base station
 - MCC, MNC, TN, FN, MFN
 - BER before Viterbi
 - AACH BER
 - Frequency error and phase error
 - SNR
 - Delay spread
 - In-band spectrum
 - Constellation diagram
 - BCH demodulation, incl. decoding of neighboring cells
 - Measurement of co-channel interference
 - Channel impulse response (channel sounder)

The R&S®ROMES4TEP software option controls Sepura, EADS and Motorola radios via the standardized PEI interface to control calls and transfer data in order to emulate user behavior in the network and provide additional status information. The R&S®ROMES4TED software option works with Sepura radios and provides layer 3 information for calculating KPIs of QoS measurements, including handover and neighborhood analysis.

The R&S®ROMES4NPA network problem analyzer completely supports analysis of TETRA QoS using R&S®ROMES4N11 and R&S®ROMES4N15 for coverage and interference and R&S®ROMES4N17 for handover and neighborhoods.

The TETRA spectrum scan displays all channels in a 10 MHz band



Application: LTE

Requirements

- R&S®ROMES4
- R&S®ROMES4SAM (Samsung driver)
- R&S®ROMES4QC (Qualcomm LTE driver)
- R&S®ROMES4T1W or R&S®ROMES4T1E (scanner driver)
- R&S®TSMW scanner or R&S®TSME scanner or R&S®TSMA


Coverage analysis with Rohde & Schwarz scanners

This essential analysis determines whether an LTE signal of sufficient strength is available at the test site. R&S®ROMES4 and TopN View can be used to clearly display the results and plot them on a map. For signal strength, the R&S®TSMW, R&S®TSME and R&S®TSMA scanners deliver the RSRP value or the power of the P-SYNC/S-SYNC signals. In addition to signal strength, the reference signal received quality (RSRQ) and the signal to interference-plus-noise ratio (RS-SINR) for each cell as well as the SINR for the SYNC signals are displayed. If one of these values is too low, this indicates interference, intermodulation or other types of disturbance. In this case, the R&S®TSMW/R&S®TSME/R&S®TSMA and R&S®ROMES4 offer a more detailed cause analysis.

Data throughput measurements with the LTE test mobile phone

R&S®ROMES4 collects scanner data and measurement data from the Qualcomm or Samsung LTE test mobile phone. One of the most important parameters is data throughput. If it is too low, the cause may be a low-order modulation format such as QPSK or the use of SISO rather than MIMO. A comparison with the scanner data permits further conclusions about possible causes. Interference, multipath propagation, handover failures or even weak network coverage might be the cause of error.

TopN View shows eNodeBs signals sorted by strength



In addition to measuring data throughput, measurement data of layer 1 and layer 3 messages is recorded. Qualcomm or Samsung chipset based LTE mobile phones or data sticks display detailed information about individual data packages so that often a quick glance is enough to detect possible causes of error.


VoLTE measurements

LTE is also increasingly used for voice transmission. IP-based telephony via VoLTE places higher demands on network quality because users have less tolerance for poor voice call quality, such as dropped calls, than they do for data calls. In addition to the normal chipset trace data, R&S®ROMES4 also supports output of the SIP signaling used for VoLTE. This makes it possible to collect voice KPIs for VoLTE and identify the cause of errors.

Interference analysis

LTE is a single frequency network (SFN) that is identified by a reuse factor of 1. This means that neighboring cells use the same frequency ranges. Interference is therefore especially frequent and must be analyzed to avoid capacity losses to the greatest possible extent. This is a special challenge for T&M equipment because the interference can also affect the T&M equipment itself. The R&S®TSMW was developed specially for this task and features an impressive C/I value of -20 dB. Even signals that are 20 dB weaker than the strongest noise can be measured, making it possible to identify interferers and reduce interference. The R&S®TSMW can also distinguish between signals that have the same physical cell ID but come from different eNodeBs. It makes no difference whether the measurement is performed in the FDD mode or in the TDD mode.

Display of measurement data from a Qualcomm chipset based LTE data stick



Cyclic prefix analysis

A special feature of the Rohde&Schwarz LTE drive test solution based on the R&S®TSMW, R&S®TSME and R&S®TSMA is the channel impulse response (CIR) measurement. This involves a channel measurement performed over a period of time. R&S®ROMES4 displays the multipath propagation of the signals – also referred to as echos – in a power vs. time diagram. As an OFDM standard, LTE has a defined frame length and a fixed guard interval, also referred to as a cyclic prefix. This value is necessary in order to wait for echos in the receiver. A cyclic prefix that is too short or an echo that is too long can cause problems in the subsequent frames. This is referred to as intersymbol interference (ISI). The effect manifests itself in a low SINR. R&S®ROMES4 can measure the length of the cyclic prefix and match it against the multipath propagation. This enables the user to draw a conclusion about how often multipath propagation disturbs the subsequent symbol, whether a longer cyclic prefix would be better and whether the network needs to be optimized, e.g. by adding eNodeBs.


Demodulation of eNodeB broadcast information

The R&S®TSMW, R&S®TSME and R&S®TSMA can scan LTE signals and also demodulate broadcast signals. The broadcast information from previously detected eNodeBs is demodulated (MIB and SIBs) to learn more about the base station. Based on this information, the user knows the country, the network and the cell from which the received signal originates. Neighborhood relationships (intra-RAT and inter-RAT) and handover thresholds are also visible. All these values make it easier to classify the signals and detect problem spots.

Subband measurements

The LTE wireless communications standard permits channel bandwidths of 1.4 MHz to 20 GHz. While the synchronization and broadcast information is contained within a bandwidth of approximately 1 MHz in the center of the LTE carrier, useful data is transmitted over the entire bandwidth. Narrowband interference outside the center of the carrier can be detected through subband measurements performed on the LTE scanner. The SINR of the reference signals is determined for every resource block (12 subcarriers corresponding to 180 kHz). R&S®ROMES4 graphically displays these values in a waterfall diagram. Interferers are visible as vertical lines in the diagram.


CIR View shows the channel impulse response (CIR) and all parts of the multipath propagation (echos) together with a cell's cyclic prefix



MIMO measurements

MIMO plays an essential role in achieving high data rates in LTE networks. Ideally, using MIMO 2x2 will double the data rate and MIMO 4x4 will quadruple the data rate. Whether this is possible in each specific case depends on the characteristics of the radio channel. The characteristics can be measured using the R&S®TSMW for MIMO 2x2 or a set of R&S®TSME for MIMO 2x2 and 4x4 together with the R&S®TSMW-K30 MIMO option. The scanner receives the eNodeB reference signals from all transmit antennas at its independent frontends. These signals are then used to determine the transmission matrix for the radio channel and the condition number. The condition number describes how successfully MIMO can be used. If the condition number is low, the radio channel is suited for MIMO. The MIMO and SINR measurements can be used to explain the data rates achieved with the test mobile phone.

Decoding of LTE BCH information by R&S®TSMW LTE scanner



Ordering information

Designation	Type	Order No.
R&S®ROMES4 drive test software		
Platform for measurement and replay	R&S®ROMES4	1117.6885.04
Software replay version	R&S®ROMES4REP	1117.6885.34
Software maintenance contract and single software update		
Software maintenance contract for one year	R&S®ROMES4UPC	1510.8140.02
One-time software update within the R&S®ROMES4 generation	R&S®ROMES4UPS	1510.8140.03
One-time software update from the previous R&S®ROMES generation	R&S®ROMES4UPG	1510.8140.04
Scanner and receiver drivers		
R&S®TSMW driver	R&S®ROMES4T1W	1117.6885.02
R&S®TSME6, R&S®TSME, R&S®TSMA and R&S®TSMA6 driver	R&S®ROMES4T1E	1117.6885.82
CW option for R&S®ROMES4 and Rohde&Schwarz receivers	R&S®ROMES4CW	1117.6885.08
Test mobile phone/data card drivers		
Qualcomm LTE/WCDMA/GSM	R&S®ROMES4QC	4900.5241.02
Qualcomm 5G NR UE	R&S®ROMES4NRQ	4900.5341.02
C2K Qualcomm CDMA2000® 1xEV-DO	R&S®ROMES4C2K	1117.6885.06
WLAN Windows	R&S®ROMES4WF2	1522.8211.02
Samsung LTE/WCDMA/GSM	R&S®ROMES4SAM	1529.8100.02
Qualcomm eMBMS	R&S®ROMES4EMQ	1527.2034.02
Qualcomm NB-IoT	R&S®ROMES4NBQ	4900.5258.02
LTE carrier aggregation, downlink	R&S®ROMES4CA	1117.6885.90
LTE carrier aggregation, uplink (Qualcomm)	R&S®ROMES4CAU	4900.5270.02
LTE licensed assisted access	R&S®ROMES4LAA	4900.5312.02
VoLTE	R&S®ROMES4VO	1522.8186.02
Neul NB-IoT	R&S®ROMES4NBN	4900.5287.02
TETRA drivers (PEI) from Sepura incl. L3	R&S®ROMES4TET	1506.9930.02
QualiPoc test mobile support		
QualiPoc single phone support	R&S®ROMES4QP	49.00.5235.02
Special measurements and options		
Automatic channel detection	R&S®ROMES4ACD	1506.9869.03
GSM interference	R&S®ROMES4COI	1117.6885.56
Position estimation	R&S®ROMES4LOC	1117.6885.32
KPI enhancement: generation and measurement of user-specific KPIs	R&S®ROMES4KPI	1117.6885.66
Handover/neighborhood analysis for 3GPP (HOA/NBA 3GPP)	R&S®ROMES4HOA	1117.6885.22
Indoor	R&S®ROMES4IND	1117.6885.24
360 degree panorama measurement with R&S®HE300	R&S®ROMES4PAN	1117.6885.78
Remote control of scanner measurements	R&S®ROMES4RCO	1506.9917.02
Printed manual	R&S®ROMES4DOC	1117.6885.14
Network problem analyzer (NPA)		
Network problem analyzer, base package	R&S®ROMES4NPA	1510.9276.02
NPA extended NQA plugin	R&S®ROMES4N11	1510.9299.11
Coverage plugin	R&S®ROMES4N15	1510.9424.02
Neighborhood analysis plugin	R&S®ROMES4N17	1510.9299.17
Spectrum analysis plugin	R&S®ROMES4N18	1117.6885.74
BTS evaluation	R&S®ROMES4N19	1522.8940.02
2G/3G/4G data plugin	R&S®ROMES4N20	1510.9299.20
Downlink carrier aggregation analysis plugin	R&S®ROMES4N21	1521.5360.02
VoLTE analysis plugin	R&S®ROMES4N22	1521.5377.02
Uplink carrier aggregation analysis plugin	R&S®ROMES4N23	4900.5306.02

Designation	Type	Order No.
Delta and comparative analysis plugin	R&S®ROMES4N30	1510.9299.30
LTE MIMO and downlink allocation analyzer	R&S®ROMES4N31	1510.9299.31
NB-IoT analysis plugin	R&S®ROMES4N34	4900.5206.02
NB-IoT UE analysis plugin	R&S®ROMES4N35	4900.5264.02

Your local Rohde&Schwarz expert will help you find the optimum solution for your requirements.
To find your nearest Rohde&Schwarz representative, visit www.sales.rohde-schwarz.com

Related products

Mobile network scanners

R&S®TSMA6 ultracompact drive test scanner



- No limitation in 3GPP frequency bands up to 6 GHz (e.g. 5G NR, LTE, WCDMA, GSM, NB-IoT), including a multi-GNSS receiver for uninterrupted location tracking
- Integrated high-performance Intel i7 CPU based PC

Combination of the technology of the R&S®TSME6 multitechnology network scanner with a high-performance Intel CPU based PC

The R&S®TSMA6 scanner supports the measurements of all supported technologies from 350 MHz to 6 GHz simultaneously. The future-proof architecture and in-field upgradability for both hardware and software allows up to MIMO 4x4 measurements and supports 5G NR technology requirements.

R&S®TSME6 ultracompact drive test scanner



- Multiband support from 350 MHz to 6 GHz
- GSM, WCDMA, LTE FDD, LTE TDD, CDMA2000®, 1xEV-DO, TETRA, WiMAX™ and spectrum analysis simultaneously in one scanner

All bands, all technologies simultaneously, ready for future 5G NR standard

The R&S®TSME6 is designed for efficient drive and walk testing with a maximum degree of freedom and upgradability. With its ultracompact design, multiband and multitechnology support and readiness for the future 5G NR standard, the R&S®TSME6 is a state-of-the-art measurement device.

R&S®TSMA autonomous mobile network scanner




- Multiband support from 350 MHz to 4.4 GHz
- GSM, WCDMA, LTE FDD, LTE TDD, CDMA2000®, 1xEV-DO, TETRA, WiMAX™ and spectrum analysis simultaneously in one scanner
- Connects to Windows PC, Android UE or tablet

Walk and drive testing with flexible connectivity

The compact R&S®TSMA autonomous mobile network scanner offers all that is needed for walk tests and drive tests. WLAN or Bluetooth® connects the smartphones/tablets used for data collection. The autonomous mobile network scanner can also run comprehensive drive test software, such as R&S®ROMES4, on its built-in i5 processor. Multitechnology and multiband measurements provide full flexibility.

R&S®TSME ultracompact drive test scanner



- Multiband support from 350 MHz to 4.4 GHz
- Up to eight technologies simultaneously in one scanner
- Compact, lightweight design

All bands, all technologies, simultaneously

The extremely compact R&S®TSME offers all that is required for mobile use. Multitechnology measurements and multiband support provide full flexibility and an optimal price/performance ratio for both drive tests and walk tests.

R&S®TSMW universal radio network analyzer




- User-definable input frequency range from 30 MHz to 6 GHz
- Parallel measurements in GSM, WCDMA, LTE, CDMA2000®, 1xEV-DO, TETRA and WiMAX™ networks with the R&S®ROMES4 drive test software

Scanner for drive tests and I/Q streaming

The R&S®TSMW universal radio network analyzer is a platform for optimizing all conventional wireless communications networks. Two frontends for any input frequency from 30 MHz to 6 GHz, preselection and software-defined architecture offer unsurpassed performance while providing maximum flexibility. In addition to functioning as a scanner for wireless communications networks, the R&S®TSMW is also an ideal digital I/Q baseband receiver.

Drive test scanner for CW measurements


The R&S®TSML-CW radio network analyzer is ideal for distance triggered CW measurements.



- Wideband receiver (80 MHz to 6 GHz)
- Support of distance triggered CW measurements

Test mobile

QualiPoc Android



Rich set of service tests for voice quality, data, messaging and video quality to reflect the real end user experience

Smartphone based product for optimizing mobile networks

QualiPoc Android is based on the latest commercial Android smartphones. It supports all mobile network technologies used worldwide, and covers multiple protocol layers as well as the IP stack in realtime. QualiPoc Android provides extensive test functions for voice, including MOS, data, video streaming, and messaging tests to assess and reflect the real end-user experience (QoS/QoE) within a mobile network.

CDMA2000® is a registered trademark of the Telecommunications Industry Association (TIA - USA).

WiMAX Forum is a registered trademark of the WiMAX Forum. WiMAX, the WiMAX Forum logo, WiMAX Forum Certified, and the WiMAX Forum Certified logo are trademarks of the WiMAX Forum.

Service that adds value

- ▮ Worldwide
- ▮ Local and personalized
- ▮ Customized and flexible
- ▮ Uncompromising quality
- ▮ Long-term dependability

Rohde & Schwarz

The Rohde & Schwarz electronics group offers innovative solutions in the following business fields: test and measurement, broadcast and media, secure communications, cybersecurity, monitoring and network testing. Founded more than 80 years ago, the independent company which is headquartered in Munich, Germany, has an extensive sales and service network with locations in more than 70 countries.

www.rohde-schwarz.com

Mobile network testing

The company's broad and diverse product portfolio for mobile network testing addresses every test scenario in the network lifecycle – from base station installation to network acceptance and network benchmarking, from optimization and troubleshooting to interference hunting and spectrum analysis, from IP application awareness to QoS and QoE of voice, data, video and app-based services.

www.mobile-network-testing.com

Sustainable product design

- ▮ Environmental compatibility and eco-footprint
- ▮ Energy efficiency and low emissions
- ▮ Longevity and optimized total cost of ownership

Certified Quality Management
ISO 9001

Certified Environmental Management
ISO 14001

Regional contact

- ▮ Europe, Africa, Middle East | +49 89 4129 12345
customersupport@rohde-schwarz.com
- ▮ North America | 1 888 TEST RSA (1 888 837 87 72)
customer.support@rsa.rohde-schwarz.com
- ▮ Latin America | +1 410 910 79 88
customersupport.la@rohde-schwarz.com
- ▮ Asia Pacific | +65 65 13 04 88
customersupport.asia@rohde-schwarz.com
- ▮ China | +86 800 810 82 28 | +86 400 650 58 96
customersupport.china@rohde-schwarz.com

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG

Trade names are trademarks of the owners

PD 5214.2062.12 | Version 15.00 | January 2019 (ch)

R&S®ROMES4 Drive Test Software

Data without tolerance limits is not binding | Subject to change

© 2009 - 2019 Rohde & Schwarz GmbH & Co. KG | 81671 Munich, Germany



5214206212